

PBK15FM
Two-way Powered Sound Reinforcement Enclosure



English

PBK15FM

Two-way Powered Sound Reinforcement Enclosure

- 15" heavy-duty woofer
- 14Ti[™] compression driver, with 1.4" titanium diaphragm
- 100W peak available power
- · Bass & Treble controls for adjusting lows and highs
- · Horn loaded compression driver tweeter for crystalline highs
- Line Input is via a female RCA phono jacks input
- Mic Input is via a female XLR with balanced input $\sqrt{1/4}$ phone jack and two wireless microphones input
- Can be operated on internal battery or external 12V power source.
- Line output is via RCA phone jack
- USB/FM/BLUETOOTH input port for MP3 file playback
- · Durable plastic injection-molded enclosure
- · Heavy-duty perforated steel grille, with powder coat finish
- Pole mount molded-in for 1 3/8" diameter poles

Description

The PBK15FM is a two-way sound reinforcement system based on a heavy-duty 15" woofer and a 14Ti[™] titanium diaphragm dynamic compression driver mounted on a medium coverage horn. It's sleek modern appearance coupled with excellent performance offer an outstanding package.

The lightweight yet rugged injection-molded plastic enclosure with molded-in stand mount cup facilitates portable use for live music or PA sound. The rounded profile cabinet has three handles for ease of portability. A black powder coated perforated steel grille provides woofer protection and a professional appearance.

The PBK15FM speaker system power amplifier is a low-distortion reliable passive air-cooled unit providing 100W peak available power for the system.

Cooling is provided via a large heat sink for low-noise and reliable operation under any conditions.

Line Input is via two RCA phono jacks to the preamp/EQ electronics, and a level control. Mic input is via a female XLR with balanced input, and a 1/4" phone jack. A Line Output has two RCA phone jack connector. These outputs allow linking of additional speaker systems, or feed of the signal to a powered subwoofer, etc.


Additionally, a USB/FM/BLUETOOTH input port is provided to allow playback of MP3 files via a USB thumb drive.

PBK15FM can be powered via internal battery, or via external 12V power source (e.g. car battery).

Applications

The Peavey PBK15FM has a variety of applications such as sound reinforcement, public address, side fill system, karaoke or musical playback.

A typical signal source for the line-level inputs of the Peavey PBK15FM would be a sound reinforcement mixing console (mixer) or the output from a CD player, MP3 player or tape deck. A dynamic microphone can be connected to the Mic Input and used as well.



VOLTAGE SELECTION PROCESS

CAUTION: Always disconnect AC power cord from unit, or AC power source before attempting to change fuse/voltage selector position!



WARNING!: Before AC power is applied to this device, always insure proper operating voltage selection is engaged to match AC power source being used.

voltage selection (2) may select 110-120V AC or 220-240V AC

The fuse should be changed to the correct amperage rating. For an input power voltage range of from 110VAC to 120VAC, use a 3.15 amp rated, 250V 5 x 20 mm cartridge type time-delay fuse, which conforms to the international fuse classification "T3.15AL". For an input power voltage range of from 220VAC to 240VAC, use a 1.6 amp rated, 250V 5 x 20 mm cartridge type time-delay fuse, which conforms to the international fuse classification "T1.6AL".

The IEC power cord that is correct for your locale can now be plugged into the IEC receptacle (3), and the Power switch (1) activated to turn on the powered PBK15FM speaker system.

ON-OFF SWITCH (1)

This rockers witch supplies AC power to the PBK15FM when switched to the ON position. The ON position is with the top side of the switch pushed "in" or nearly flush with the rear panel.

FUSE (2)



The unit is AC power line fuse protected from overloads and fault conditions with a slow-blow 5 x 20mm 250V fuse. This fuse is located within the base of the IEC power cord

connector (2), just below the IEC connector blades. If the fuse fails, THE FUSE MUST BE REPLACED WITH THE SAME TYPE AND VALUE IN ORDER TO AVOID DAMAGE TO THE EQUIPMENT AND TO PREVENT VOIDING THE WARRANTY!

The fuse in the Peavey PBK15FM can be replaced with a time-delay type 5 x 20 mm size 250V rated fuse.

For 110-120VAC operation, a fuse rated at 3.15 amps and 250V should be used, which conforms to the international fuse classification "T3.15AL".

For 220-240VAC operation a fuse rated at 1.6 amps and 250V should be used, which conforms to the international fuse classification "T1.6AL".

If the unit continues to blow replacement fuses, do not keep replacing them, it should be taken to a qualified service center for repair.

To replace the fuse, be sure to remove the IEC power cord from the IEC socket. The fuse holder tray is located beneath the IEC socket cavity. Pry the fuse holder tray out with a small flat blade screwdriver placed under the center of the top edge of the fuse tray, and gently lever the fuse tray out. The fuse is held in a clip in the fuse tray, and should be removed and replaced with a fresh 5 X 20mm 250V type fuse of the appropriate current rating.

Then, once the fresh fuse has been put in place, re-insert the fuse tray into the IEC connector assembly, making sure that the voltage range selection is correct (see above section) and make sure it is fully seated and flush with the outside of the IEC connector assembly.

IEC POWER CORD CONNECTION (3)



This receptacle is for the IEC line cord (supplied) that provides AC power to the unit. It is very important that you ensure the PBK15FM has the proper AC line voltage supplied. You can change the voltage for your PBK15FM by following the instructions above under the section VOLTAGE SELECTION PROCESS.



Please read this guide carefully to ensure your personal safety as well as the safety of your equipment. Never break off the ground pin on any equipment. It is provided for your safety. If the outlet used does not have a ground pin, a suitable grounding adapter should be used and the third wire should be grounded properly. To prevent the risk of shock or fire hazard, always be sure that the mixer and all other associated equipment are properly grounded.

External power (4)

External battery supply 12VDC

Battery charging indication(5)

CONSTANT VOLTAGE CHARGE CYCLE USE: 14.5 - 14.9V

STANDBY USE: 13.5 - 13.8V INITIAL CURRENT: LESS THAN 2.1A

WIRELESS MICROPHONES(6)

Press ON/OFF switch, PWR indicator light, The wireless receiver module is working.

PEAK(7)

Indicator cavity peak signal. Ignition to detect an input signal with a high or high output level that may cause a failure

POWER LED (8)

Illuminates green when the power switch is on and power is present

MASTER VOLUME CONTROL (9)

It is used to directly set the system output level for a given set of input channel input signals

ECHO CONTROL (10)

This controls the amount of Echo effect that is added back to the output signal.

BASS CONTROL (11)

The Bass control provides a boost or cut of lower frequency content, such as bass guitar, so that the tonal balance can be adjusted depending on the signal source. Do not use excessive boost when playing sound at loud levels, as the boost is not needed then.

TREBLE CONTROL (12)

The Treble control provides a boost or cut of higher frequency content, such as cymbals, so that the tonal balance can be adjusted depending on the signal source. Do not use excessive boost when playing sound at loud levels, as the boost is not needed then.

LINE LEVEL INPUTS (13)

The line-level inputs are of the medium impedance type. A pair of RCA phono connectors is available. Note the RCA jacks do not denote stereo operation, the signal from both jacks is summed together into one signal that is fed to the speakers.

LINE OUT (14)

These RCA jacks are intended for the use of linking multiple PBK15FM in a line or to provide a feed to a powered subwoofer, or other electronics that needs to receive a full range version of the input signal. The connectors available are RCA jack.

Signal input selector switch(15)

Signal input selector. You can select between the line inputs and the media (USB/FM radio/BT) inputs.

LINE IN LEVEL (16)`

Controls the gain or output level of the line level input signal.

MIC INPUT (17)

The Mic level input is of the low impedance type. The jacks are a female XLR and a 1/4" phone connector. Gain is much higher than the line level inputs.

THIS INPUT SHOULD NOT BE USED FOR LINE LEVEL SIGNAL INPUT, AS IT WILL OVERLOAD AND DISTORT, DESPITE THE MASTER VOLUME CONTROL OR THE MIC GAIN CONTROL BEING TURNED DOWN!

MIC GAIN (18)

Controls the gain for the microphone inputs.

Media Playback Buttons (19)

MODE: A short press of the MODE button will toggle between the USB input, FM Radio and Bluetooth. A long press of the MODE button will enter the setting menu for whichever source is selected. In the settings menu, you can select things like the pre-programmed EQ modes and the repeat functions. In the FM Radio settings, you can Auto search for stations, delete stations or delete all the stations. There are no settings available for the Bluetooth.

PLAY/PAUSE: A short press of the PLAY/PAUSE button causes the operation to change from PLAY to PAUSE or from PAUSE back to PLAY.

STOP: Press the STOP button to stop a file that is playing.

REPEAT: Pressing the REPEAT button toggles the function between ALL, REPEAT ONE, REPEAT FOLDER, NORMAL, RANDOM and BROWSE.

ALL: Repeats all songs.

REPEAT ONE: Repeats a single song.

REPEAT FOLDER: Repeats all the songs in a single folder.

NORMAL: Plays all songs in order.

RANDOM: Plays all songs in a random order.

BROWSE: Plays the first 10 seconds of each song.

TRACK SKIP: In playback mode the TRACK SKIP buttons let you select the track to play. A short press skips to the next track. A long press allows you to fast forward/rewind through a song. Hold the button down until the desired playback point is found. Release the button and the song will start playing. The TRACK SKIP buttons are used to increment/decrement through the options in the menu.

DISPLAY (20)

Digital display for USB MP3 functions



USB PORT (21)

For connection of a USB thumb drive for MP3 file playback. DO NOT PLUG A USB CABLE FROM A COMPUTER INTO THIS PORT! The PBK15FM USB MP3 input, and/or the computer USB output can be damaged as a result.

Bluetooth® Player

To listen to your music via Bluetooth wireless connection, you need to pair (link) your PBK 15FM with your Bluetooth phone and/or music device.

- 1. Turn off any Bluetooth devices previously paired with your PBK 15FM.
- 2. Turn on the Bluetooth feature on your phone or music device.
- 3. Press the mode button until the Bluetooth symbol appears in the upper left hand corner of the LCD display.
- 4. Place your phone or music device in Bluetooth search mode.
- 5. Select Bluetooth audio from search results on your phone or music device.
- 6. Select OK or YES to pair your speaker system with your phone or music device.

When your PBK 15FM successfully pairs and connects with your phone or music device, the LCD display will indicate the name of the device connected. You will now be able to play music from your connected music source through your PBK 15FM. The level can either be adjusted from the connected source or by the MP3 Volume control. * Wireless range can vary depending on Bluetooth class of source device, and be subject to interference from obstructions such as walls or other electronic devices.

Remote Control





NOTE: For proper use, do not block the IR Receiver.

PLAY/PAUSE: A short press of the PLAY/PAUSE button causes the operation to change from PLAY to PAUSE or

from PAUSE back to PLAY

CH- / CH+: Channel adjustment buttons.

EQ: EQ Preset adjustment button.

- / +: Volume adjustment buttons.

l<</pre>/ >>I: Track skip buttons let you select the track to play.

0-9: Directly access tracks.

PICK SONG: N/A on this model

ENTER: Enters the settings menu.

MODE: Toggles between the USB input, FM radio and Bluetooth.

For ease of use and convenience, a remote control comes with the PBK 15FM (battery included). To replace the battery, push in left tab and pull out. Use only a CR2025 model battery as a replacement.

WARNING

Do not ingest the battery. Chemical Burn Hazard.

(The remote control supplied with) This product contains a coin/button cell battery. If the coin/button cell battery is swallowed, it can cause severe internal burns in just 2 hours and can lead to death.

Keep new and used batteries away from children.

If the battery compartment does not close securely, stop using the product and keep it away from children.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.

Frequency Range:

1 m on-axis, swept-sine in 1/2 Space environment, +/-6dB:

54 Hz to 20 kHz

Nominal sensitivity (1W @1m, swept sine input in anechoic environment):

98 dB (average)

Maximum Sound Pressure Level (1 meter):

122 dB SPL peak with music

Transducer Complement:

Heavy-duty 15" woofer

14Ti™ 1.4" titanium diaphragm dynamic compression driver, mounted on a semi-exponential horn.

Nominal Coverage Pattern:

60 degrees horizontal by 45 degrees vertical

Electroacoustic crossover frequency:

2,700 Hz

Crossover type:

Internal passive two-way crossover with driver EQ, and level matching,

Crossover Slopes:

12 dB/octave (2nd order) low pass, 12dB/octave (2nd order) high pass, both with staggered poles and driver EQ.

Input Connections:

Line Level: two RCA phono jacks.

Mic Level: One female XLR , one 1/4" phone jack and two wireless microphones.

USB Input Port: For connection of a USB thumb drive/memory stick for playback of MP3 music files.

DO NOT PLUG A USB CABLE FROM A COMPUTER INTO THIS PORT!

The PBK15FM USB MP3 input, and/or the computer USB output can be damaged as a result.

Output Connections:

two RCA phone jack. The Line Out jacks are intended for the use of linking multiple PBK15FM in a line or to provide a feed to a powered subwoofer, or other electronics that needs to receive a full range version of the input signal.

Enclosure Materials & Finish:

Black ABS plastic with textured surface, black powder-coated perforated grille.

Mounting or Suspension: Molded-in 1 3/8" pole-mount cup for stand mounting, four rubber feet for floor use.

NOTE: This unit is not designed for overhead suspension!





Overall Dimensions (H x W x D):

27.56" x 17.90" x 13.80"

(700mm x 455mm x 350mm)

Net Weight:

47 Lbs. (21.0 kg)

Electronics and Amplifier Specifications:

Internal power amplifier (@120 VAC line):

100 watts peak available power

Continuous Power: 50 watts @ less than 3% THD

Electronic Input Impedance (Nominal):

Line: 10 k ohms unbalanced RCA

Mic: 2.2 k ohms balanced (XLR) No phantom power available.

Input Sensitivity for Full Output (Level full CW):

Line Level – 0.36 V RMS Mic Level – 0.02 V RMS

Tone Control Corner & Range:

Bass: +/- 12 dB, corner @ 100 Hz, Treble: +/- 12 dB, corner @ 10kHz

Nominal Amplifier Frequency Response (before EQ):

+1, -3 dB from 20 Hz to 20 kHz

Hum and Noise:

Greater than 90 dB below rated power

THD and IM:

Typically less than 1 %

Power requirements of Peavey PBK15FM System:

Nominal 50 Watts, 100-120 VAC 50-60 Hz

Fuse Type:

For 110-120 VAC USE: International fuse classification T3.15AL cartridge-style 5 x 20 mm size fuses with a 250V rating can be used.

For 220-240VAC USE: International fuse classification T1.6AL . This is a cartridge style 5 x 20 mm size time-delay fuse with a 2.0 amp 250V rating.

Features and specifications are subject to change without notice.



Warranty registration and information for U.S. customers available online at www.peavey.com/warranty or use the QR tag below



Features and speci 白 cations subject to change without notice.

Peavey Electronics Corporation 5022 Hartley Peavey Drive Meridian, MS 39305 (601) 483-5365 FAX (601) 486-1278

