




# KPX5M


## MINI-MONITOR




### **Congratulations on the purchase of your Kustom KPX5M**

This personal monitor combines quality performance and convenient features, all in a highly portable package. You'll find that the KPX5M works well in a variety of environments, amplifying vocals, instruments, keyboards, drum machines, music and more. This manual will help get you up and running quickly. We wish you many years of enjoyment from your Kustom KPX5M.

## CONTROLS & FEATURES OVERVIEW



- 1. HIGH:** Turned clockwise, this control accents treble frequencies to produce clearer, crisper sound. Turn counterclockwise to make the sound softer and less bright.
- 2. MID:** Turned clockwise, this control accents midrange frequencies to produce a louder sound, especially in the vocal range. Turn counterclockwise to reduce harsh sounds for a more pleasing listening experience.
- 3. LOW:** Determines the emphasis of bass frequencies. Turning this knob clockwise creates a deeper, warmer tone. When using for vocals at high volumes, turn counterclockwise to allow vocals to cut through the mix.
- 4. LEVEL:** Use these controls to adjust the volume level of each channel and the relative balance between them.
- 5. INPUTS** These inputs are designed for XLR and 1/4" cables. The XLR portion is for low-impedance microphones or equipment that has a mic-level, balanced output (often called a Direct out). The 1/4" portion of these inputs may be used to connect high-impedance microphones, keyboards, drum machines and other line level audio devices.
- 6. MASTER:** Controls the overall volume of all channels.  
Note: Does not affect output of Thru jacks.
- 7. AUX IN:** Use this 1/8" stereo input to connect an external audio device such as an MP3, CD player or computer for playback.  
Note: Right and Left channels are summed to mono on this input.



**8. Thru:** This XLR Jack is used to pass a signal from inputs 1 and 2 of the KPX5M to another device such as a mixer or powered speaker.

**9. AC Power Cord Receptacle:** Insert the KPX5M's AC cord firmly into the AC receptacle. Be sure to use the cable provided with your KPX5M. The power cord can be removed for storage

Note: Replace the AC cord if its protective jacket is damaged.

**Power:** This switch activates AC power to the monitor.

**Not Shown:** The KPX5M has a mic stand adapter socket on the bottom of cabinet.

This allows the product to be placed on a standard microphone stand for optimum monitoring.



[www.kustom.com](http://www.kustom.com)

Kustom Amplification, Inc.

859-817-7100

All specifications are subject to change without prior notice. ©2018 Kustom

