


*Fender*

---

**LOST HIGHWAY PHASER**

---



**1. Bypass Footswitch**

**2. Jewel Indicator**

**3. Output Jack**

**4. Blend**

**5. Rate 1**

**6. Rate 1 LED**

**7. Depth 1**

**8. Feedback**

**9. Center LED**

**10. Rate 2**

**11. Rate 2 LED**

**12. Depth 2**

**13. Sensitivity**

**14. Sensitivity LED**

**15. Wave Type Switch**

**16. Phase Stage Switch**

**17. Input Jack**

**18. Slow/ Fast Footswitch**

**19. LED Kill Switch**

**20. Boost Switch**

**21. DC Power Connector**



---

## LOST HIGHWAY PHASER

---

Thanks for purchasing Lost Highway Phaser — a powerful, flexible analog phaser. Foot-switchable Fast and Slow speeds—each with their own independent Rate and Depth controls—let you easily alternate between slow, moody phase shifting all the way to rapid and warped modulation. The Wave toggle switch selects between Sine and Triangle waveforms while switchable 4- and 8-stage phasing makes it easy to add extra resonance on the fly. The Sensitivity control allows modulation rate changes based on your playing dynamics—dig in and the intensity of the phasing increases.

DESIGNED IN CALIFORNIA, U.S.A.

## **Rate 1**

While the **Slow** speed is selected, the Rate 1 control adjusts the speed of the modulation.

## **Rate 1 LED**

This LED is illuminated when the **Slow** Speed is engaged. Rate 1 and Rate 2 are active when this LED is on.

## **Depth 1**

While the **Slow** speed is selected, the Depth 1 control adjusts the intensity of the phaser.

## **Center LED (LED between Depth 1 and Rate 2)**

This LED blinks in time with the rate of the Lost Highway.

## **Rate 2**

While the **Fast** speed is selected, the Rate 1 control adjusts the speed of the modulation.

## **Rate 2 LED**

This LED is illuminated when the **Fast** Speed is engaged. Rate 1 and Rate 2 are active when this LED is on.

## **Depth 2**

While the **Fast** speed is selected, the Depth 1 control adjusts the intensity of the phaser.

## **Blend**

The Blend control adjusts the Wet/Dry mix of your instrument's signal and the Lost Highway's modulated signal. When the control is set to 50%, classic phasing is achieved. When the control is set to 100%, the pedal will produce harmonic vibrato. At 0%, the pedal has no modulation effect.

## **Feedback**

The Feedback control adjusts the amount of resonance of the Phased signal. Turn the knob clockwise to add more resonance.

## **Wave Type Switch**

This switch allows you to toggle between sine and triangle shaped modulation.

## **Phase Stage Switch**

This switch allows you to toggle between 4 and 8 stage phasing.

## **Sensitivity**

When the **Slow** mode is engaged, the Sensitivity control adjusts the threshold for the Lost Highway's dynamically controlled rate. As the Sensitivity is turned clockwise, the Lost Highway can automatically switch from **Slow** to **Fast** settings with the changes in your instrument's volume—softer playing will keep the Lost Highway set to your **Slow** settings; louder playing will send the Lost Highway ramping up to your **Fast** settings. Turn the Sensitivity control fully counter-clockwise to disable this feature.

## **Sensitivity LED**

This LED will illuminate when your instrument's signal passes the threshold set with the Sensitivity control to ramp the Lost Highway's phaser speed from the **Slow** settings to the **Fast** settings.

## **Bypass Footswitch**

This footswitch is used to bypass the effect.

## **Slow/Fast Footswitch**

This footswitch is used to toggle between the Slow and Fast phasing speeds. The Slow controls are Rate 1 and Depth 1; the Fast controls are Rate 2 and Depth 2.

## **Jewel Indicator**

The Jewel Indicator shows when the phaser effect is active.

## **Input Jack**

This is a high-impedance input suitable for electric guitar, bass, acoustic guitars with pickup systems, keyboards and other instruments.

## **Output Jack**

This is a low-impedance output jack that connects to the amp or to the next effect pedal in a mono signal chain.

## **DC Power Connector**

This is a standard center-negative 9VDC jack for use with appropriate power supplies.

## **LED Kill Switch**

This switch extinguishes the LEDs that illuminate the knobs.

## **Boost Switch**

This switch allows you to add 3dB of volume to the Lost Highway's output.

A PRODUCT OF:  
**FENDER MUSICAL INSTRUMENTS CORPORATION**  
CORONA, CALIFORNIA, USA

Fender® is a registered trademark of FMIC.

Copyright © 2018 FMIC. All rights reserved.

P/N 7715388000 - REV A

---

### Important Safety Instructions

---

- **WARNING:** To prevent damage, fire or shock hazard, do not expose the unit or its AC power to rain or moisture.
- Do not alter the AC plug of the connected power adapter
- Do not drip or splash liquids on the unit.
- No user serviceable parts inside, refer servicing to qualified personnel only.
- **WARNING:** The unit must only be connected to a safety agency certified, regulated, power source (adapter), approved for use and compliant with applicable local and national regulatory safety requirements.
- Unplug the AC power adapter before cleaning the unit exterior. Use only a damp cloth for cleaning and then wait until the unit is completely dry before reconnecting it to power.
- Amplifiers and loudspeaker systems, and ear/headphones (if equipped) are capable of producing very high sound pressure levels which may cause temporary or permanent hearing damage. Use care when setting and adjusting volume levels during use.

THIS DEVICE COMPLIES WITH PART 15 OF FCC RULES. OPERATION IS SUBJECT TO THE FOLLOWING TWO CONDITIONS: (1) THIS DEVICE MAY NOT CAUSE HARMFUL INTERFERENCE, AND (2) THIS DEVICE MUST ACCEPT ANY INTERFERENCE RECEIVED, INCLUDING INTERFERENCE THAT MAY CAUSE UNDESIRE OPERATION.

---

### Additional Languages

---

Manual available in additional languages at:  
[www.fender.com/support](http://www.fender.com/support)

### Specifications

<b>IMPEDANCES:</b>	INPUT: 500kΩ	OUTPUT LOAD: >10kΩ
<b>POWER SUPPLY:</b>	9VDC regulated adapter, 5.5 x 2.1 mm barrel connector, center negative	
<b>POWER REQUIREMENTS:</b>	80mA @ 9VDC +—⊖—	
<b>DIMENSIONS:</b>	3.75" x 4.9" x 2.5" (95.25mm x 124.5mm x 63.5mm)	
<b>WEIGHT:</b>	1.2lbs (.54kg)	



Product specifications subject to change without notice



## NOTES:

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---



© FENDER MUSICAL INSTRUMENTS 2019

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
箱体	O	O	O	O	O	O
喇叭单元*	O	O	O	O	O	O
电子部分	X	O	X	O	O	O
接线端子	X	O	O	O	O	O
电线	X	O	O	O	O	O
附件	O	O	O	O	O	O

本表格依据 SJ/T 11364 的规定编制。

O: 表示该有毒有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

X: 表示该有毒有害物质至少在该部件的某一均质材料中的含量超出 GB/T 26572 规定的限量要求。

注: 含有有害物质的部件由于全球技术发展水平限制而无法实现有害物质的替代。

\*产品含有喇叭单元时有效。