







LIVE·CONSOLE

2 Mic/1-Instrument in, 2 Line out recording USB Interface with DSP effects built-in for live streaming with Smartphones



User manual



	<p>CAUTION</p> <p>RISK OF ELECTRIC SHOCK DO NOT OPEN RISQUE DE CHOC ELECTRIQUE NE PAS OUVRIR</p> <p>CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK DO NOT REMOVE COVER (OR BACK) NO USER-SERVICEABLE PARTS INSIDE REFER SERVICING TO QUALIFIED PERSONNEL</p> <p>ATTENTION: POUR EVITER LES RISQUES DE CHOC ELECTRIQUE: NE PAS ENLEVER LE COUVERCLE. AUCUN ENTRETIEN DE PIECES INTERIEURES PAR L'USAGER. CONFIER L'ENTRETIEN AU PERSONNEL QUALIFIE.</p> <p>AVIS: POUR EVITER LES RISQUES D'INCENDIE OU D'ELECTROCUTION, N'EXPOSEZ PAS CET ARTICLE A LA PLUIE OU A L'HUMIDITE</p>		<p>The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure, that may be of sufficient magnitude to electric shock to persons. Le symbol clair avec point de flèche à l'intérieur d'un triangle équilatéral est utilisé pour avertir l'utilisateur de la présence à l'intérieur du coffret de voltage dangereux non isolé d'ampleur suffisante.</p> <p>The exclamation point within an equilateral triangle is intended to alert the user of the presence of important operating and maintenance (servicing) instructions in the literature accompanying the appliance. Le point d'exclamation à l'intérieur d'un triangle équilatéral est employé pour avertir les utilisateurs de la présence d'instructions importantes pour le fonctionnement et l'entretien (service) dans le livret d'instruction accompagnant l'appareil.</p>
			
			

Important Safety Instructions

1. Read this manual thoroughly before using this unit.
2. Keep this manual for future reference.
3. Take notice of and comply with all warnings included in the user's manual or indicated on the appliance.
4. Follow all instructions included in this manual.
5. Do not expose this unit to rain or moisture. Avoid having water or other liquids spilled on this unit.
6. When cleaning the cabinet or other parts of this appliance, use only a dry or slightly damp soft cloth.
7. Do not block any ventilation openings or interfere with the proper ventilation of this unit. Install in accordance with the manufacturer's instructions.
8. Do not use or store near any heat sources such as radiators, heat registers, stoves, or other heat-producing appliances.
9. Do not interfere with the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding-type plug has two blades and a third grounding prong. These are designated for your safety. If the provided plug does not fit into your outlet, consult an electrician.
10. Protect the power cord from being walked on or otherwise damaged by items placed on or against them. Particular attention should be given to the plugs, receptacles, and the point where the cord exits the appliance.
11. To avoid the risk of electrical shock, do not touch any exposed wiring while the unit is in operation.
12. Only use attachments/accessories specified by the manufacturer.
13. Unplug this unit and all connected electrical equipment during lightning storms or when left unused a long period of time.
14. Refer all servicing to qualified service personnel. Servicing is required when the appliance has been damaged in any way or fails to operate normally.

WARNING: To reduce the risk of fire or electric shock, do not expose this unit to rain or moisture

Contents

Introduction.....	4
What's in the package?	4
Register your ICON ProAudio product to your personal account	5
Features	6
Top Panel.....	8
Front Panel	12
Assigning Samples to the sample pads.....	12
Rear Panel.....	13
Hardware Connections (with PC/Mac only).....	14
Hardware Connections (with PC/Mac only).....	15
Hardware Connections (Use as a standalone device)	15
Minimum System Requirements.....	16
Specifications	17
Services.....	18

Introduction

Firstly, congratulations on your purchase of the ICON Pro Audio Live Console digital audio Interface! In these pages, you'll find a detailed description of the features of the Live Console digital audio Interface, as well as a guided tour through its front and rear panels, step-by-step instructions for their setup and use and a full list of specifications.

Please register the product on our website at the link below

www. iconproaudio.com/registration:

As with most electronic devices, we strongly recommend you retain the original packaging. In the unlikely event that the product is returned for servicing, the original packaging (or reasonable equivalent) is required. With proper care and adequate air circulation, your Live Console digital audio interface will operate flawlessly for many years to come.

We trust that this product will provide years of excellent service and in the unlikely event that your product does not perform to the highest standard, every effort will be made to address the issue.

What's in the package?

- Live Console USB Recording Interface for live streaming
- USB cable (Type C)
- 3.5mm TRRS cable (1.2m)
- USB cable (Micro) for importing audio jingle/sample files from PC to device

Register your ICON ProAudio product to your personal account

1. Check the serial number of your device

Please go to [http:// iconproaudio.com/registration](http://iconproaudio.com/registration) or scan the QR code below.



Input your device's serial number and the other information on the screen. Click "Submit".

A message will pop up showing your device information such as model name and its serial number - Click "Register this device to my account". If you see any other message, please contact our after-sales service team.

2. Log in to your personal account page for existing users or signing up as a new user

Existing user: Please log into your personal user page by inputting your Username and password.

New user: Please click "Sign Up" and fill in all the information.

3. Download all useful materials

All your registered devices under your account will show on the page. Each product will be listed along with all its available files such as drivers, firmware, user manual in different languages and bundled software etc. for download. Please ensure you have downloaded any necessary files before you begin installing the device.

Features



The ICON Live Console USB recording interface provides an audio input and output module with USB connectivity for your PC or Smart Phone for instant live streaming capability. The main features include:

- Unique and innovative built-in ICON DSP effects for outstanding audio quality
- 14 importable jingle/sample slots with individual trigger buttons
- 8 different vocal presets & 4-different instrument presets with individual trigger buttons
- Vocal-Tune with 13-key parameter buttons including C/C#/D/D#/E/F#/#/G/G#/A/A#/B
- Pitch Shift with 12-note scale parameter individual buttons
- 4-digit display with two control knobs to control DSP parameters including Value and Speed
- 6x60mm faders for controlling different input and output values
- Easily paired Bluetooth for connecting with Smartphone BGM
- 2 mic-in or 1 mic-in/1 instrument-in, 2-out USB recording interface
- +48V phantom power
- 2 analog outputs on 1/4" TRS jacks
- Functions as a stand-alone device with DSP processing
- Attenuator (Voice-Over) "ducking" function button equipped for music fade-out automatically, when mic signal is present
- Buttons equipped for controlling mic signal (dry/wet) recording to PC/Smart Phone
- Buttons equipped for controlling monitoring signal (dry/wet)
- 2 headphone outputs on a 3.5mm stereo jack
- Smart device digital (type C) and analog (TRRS) connection jacks
- Compatible with iOS and Android Digital I/O jack (Type C) & Analog I/O jack (3.5mm stereo TRRS) and equipped for direct connection with Smart Phone.

- Compatible with Mac OS (Intel-Mac) and Windows XP, Vista (32-bit/64-bit), Windows 7 (32-bit/64-bit), Windows 10 (64-bit), Windows 11 (64 bit)
- USB2.0 compatible and USB bus-powered
- Plug & play. No driver installation is needed.

Top Panel



1. 14x24-bit DSP samplers/jingles

14 buttons are equipped to instantly trigger samples and jingles. The USB (micro) port is equipped to import your own audio files by connecting to your PC*.

14 default samples are preloaded at the factory and they are as follows;

Horrify	a horrifying sound effect sample
OMG	a 'Oh My God!' sample
Birdy	a bird flying over sound effect sample
LOL	a 'Laugh Out' Loud effect sample
Helpness	a 'helplessness' sound effect sample
Slap	a face slapping sample
Laugh	a group laughing effect sample
What	a "What??" sample
Air Horn	a series of air horn sounds, sound effect sample
Shocking	a "shocking" sound effect sample
Curosity	a "curiosity" sound effect sample
Innocent	a "innocent" sound effect sample
Beat Up	a "beaten up" sound effect sample
Fun	a croed laughing effect sample

*See 'Assigning samples to sample pads' (pg. 12) to assign your own sample sounds.

2. 12x Vocal & Instrument presets

Individual control button for 8x Vocal & 4x Instrument DSP presets as well as a Bypass button are equipped;

Vocal DSP presets	Reverb Delay
	Hall
	Room A
	Room B
	Echo A
	Echo B
	Chorus Reverb
	Stereo Chorus
Instrument DSP presets	Multi Delay
	Analog Delay
	Spring Reverb
	Plate

3. 13x Key control buttons for Vocal Tune

There are 12 Individual control buttons for controlling "Key" + 1 button to control Voice Tune as well as a Bypass button.

12 Key buttons : C/C#/D/D#/E/F/F#/G/G#/A/A#/B

Voice Tune control buttons : Major/Natural Minor/Harmonic Minor/Melodic Minor. When pressed, the central 'circle' button will illuminate as follows;



	Major: not lit
	Natural Minor: Green
	Harmonic Minor: Blue
	Melodic Minor: Red

4. 12x Semi Tone control buttons for Pitch Shift

12 Individual control buttons (1-12) for controlling "Semi Tone" as well as a Bypass button are included.

5. Bluetooth On/Off button

Press this button to activate the Bluetooth function for connecting with your mobile device for Background Music (BGM) input. A blue light will continuously flash when activated and remain lit after it has successfully paired with your mobile device.

6. +48V Phantom power On/Off button

Press to activate the +48V phantom power supply to your Ch.1 condenser microphone input.

7. Mic/Inst switch button

Press this button to switch your input to Ch.2 between a dynamic microphone or an instrument.

8. Various function controls

1. Auto Voice Over - Voice over function will activate automatically when signal is detected from microphone inputs.

2. Manual Voice Over- Press and hold to activate the Voice Over function - release to de-activate it.

3. Mic. Mute button - Press to mute all microphone input channels.

4. Monitor Mute button - Press to mute the headphone HP output.

5. Noise Reduction button - Press to activate the noise reduction function.

6. LoopBack button - Press to activate the loopback function. The signal on the type C connection (PC or mobile device) will be 'looped back' from its output to its input.

9. Mode presets

There are 6 different mode presets with different settings when using input/output, DSP effect and monitor settings etc. They are designed for different application needs. Please refer to the following table chart for the different settings in each mode.

		Chat	Music	Gaming	MC	Karaoke	Monitor : Wet Record : Dry
OTG out Signal (3.5mm/ Type C)	No DSP Effect (Microphone)	√		√		√	√
	With DSP Effect (Microphone)					√	
	AUX				√	√	√
	OTG (3.5mm / Type C)			Loop Back On/Off			
Output Signal (HP/Libe Out)	No DSP Effect (Microphone)	√			√	√	√
	With DSP Effect (Microphone)					√	√
	AUX		√		√	√	√
	OTG (3.5mm / TypeC)	√	√	√	√	√	√

Note: Aux - Including the signal sources from samplers, 3.5mm stereo line-in & Bluetooth BGM in)

OTG - Including the 3.5mm stereo jack (analog) & the Type C connector (Digital)

10. EQ (Hi / Mid / Low) control knobs

There are 3 EQ control knobs for adjusting Hi / Mid / Low EQ parameters.

11. Value & Speed encoder control knobs

There are two encoder knobs for controlling the DSP effect parameters including Value (Orange) and Speed (Blue). Adjustments to the parameters from 0-99 can be viewed on the 4-digit display.

12. Joystick

There is a joystick equipped for adjusting different values including:

Y-axis - Adjusting the modulation speed.

X-axis - Adjusting the Pitch Shift semi-tone values.

This is very useful in live performance sessions and is a valuable tool for self expression, turning your performance into a more creative, interesting and playful experience! Have fun with it!

13. Input and Output fader controls

There are 6x60mm faders for adjusting the different input gains and output volumes.

Input Ch. 1	XLR: Condenser	Slide to adjust the input gain for the "Input CH 1"
	3.5mm Jack: Dynamic	
Input Ch.2	6.35mm Jack: Inst.	Slide to adjust the input gain for the "Input Ch.2".
	6.5mm Jack: Dynamic	
Input Ch.3	Slide to adjust the input gain for the "Input Ch.3" - 3.5mm stereo line in.	
Mobile (OTG Output)	Slide to adjust the output volume of the OTG output including the 3.5mm stereo jack (Analog) and Type C (digital).	
Master Output	Slide to adjust the output volume of the Master output - 6.35mm L/R output jacks.	
HP Output	Slide to adjust the output volume of both HP 1/2.	

Front Panel



1. HP Output jacks 1/2

These output jacks accept a standard 3.5mm stereo TRS connector.

2. Infrared sensor

Sensor for the infrared remote control (optional).

Note: An optional device, “LiveRemote”, is available for triggering sound samples etc. remotely. This could be extremely useful when live streaming. Please contact your nearest Icon dealer for product information.

Assigning Samples to the sample pads

1	Connect the micro USB cable provided to the Samples input jack with your PC to import audio files for samples. There are 14 sample slots available.
2	When connected to a PC, you will see a mobile USB disk named ICON_LVC.
3	Open it. You will see 14 folders, labelled from 01 to 14, each folder corresponding to one sample, from 1 to 14 labelled on each button.
4	Click and drag your pre-prepared sample into the folder that corresponds to the desired button on your device.
5	After you have finished assigning samples, please eject the USB disk on your PC.
6	Unplug the micro USB cable as you will not be able to hear the sample while the micro USB cable is inserted.

Rear Panel



1. Mic Input Ch. 1

An XLR connector for use with condenser microphones and a 3.5mm jack for connecting dynamic microphones.

2. Mic Input Ch. 2

A 6.35mm connector for connecting an instrument such as a guitar and a 6.35mm mono jack for connecting a dynamic microphone

3. 3.5mm TRS input connectors (Line in)

Unbalanced analog inputs with a 3.5mm TRS connector at -10dB line level.

4. 3.5mm TRS output connectors (Line Out L/R)

Unbalanced analog outputs with standard 3.5mm TRS connectors at $+6\text{dB}$ line level.

5. 6.35mm Line outputs L/R

Unbalanced analog outputs with standard 6.35mm TRS connectors at $+6\text{dB}$ line level.

6. OTG connectors (Analog & Digital)

Analog - 3.5mm TRRS Smart Phone connection jack Connect this jack with the cable provided, to your smart phone's headset input jack.

Digital - USB 2.0 compatible Connector (Type-C) Connect it with the USB cable provided, to your Mac/PC's USB connector. When running the live streaming application, connect it with an OTG cable which allows you to connect to your smart phone.

7. 5V charging port (Type C)

Connect with a standard Type C cable to charge the internal rechargeable battery of Live Console.

8. Power On/Off switch

Switch to turn the device on or off.

9. Samplers upload port (micro USB)


Connect the micro USB cable provided to this jack with your PC to import audio files for samples. There are 14 sample slots available.

Hardware Connections (with PC/Mac only)

- 1. Connect the Live Console digital audio interface outputs to your amplifier, powered monitors or surround system. This operates as a two- channel stereo output. The default outputs are channels 1 and 2.
- 2. If monitoring through headphones, connect the headphones to the device's headphone output.
- 3. Connect your microphone to the device's analog input.



Hardware Connections (with PC/Mac only)



Hardware Connections (Use as a standalone device)



Minimum System Requirements

Important: The Live Console digital audio interface is supported by Mac OS (Intel-Mac / M1), Windows 7 (32-bit/64-bit) and Windows 10/11 (32-bit/64-bit). The Live Console digital audio interface is not supported by Windows 98 or Windows Me. For Windows XP, you must be running SP1 or later. Visit the Windows update web pages to ensure you have the most current updates and fixes supplied by Microsoft. With regard to the Mac, the Live Console digital audio interface is supported by Mac OSX version.

10.11.6 (El Capitan) or later (must be Intel-Mac). Earlier versions of Mac operating systems are not supported.

Windows OP:

Pentium 4 -1.0GHz or higher 1.0Ghz RAM

DirectX 8.1 or higher

Windows XP (SP1), Windows 2000 (SP3), Windows Vista, Windows 7 or Windows 10/11

Mac OP:

Intel-Mac 1.0GHz or higher 1.0GHz RAM

OS 10.11.6 or later

Specifications

Mic Input:

Frequency Response: 22Hz to 20kHz (+/-0.2dB)
Dynamic Range: 90dB, A-weighted
Signal-to-Noise Ratio: -90dB, A-weighted
THD+N: <0.0061% (-86dB)
Crosstalk: -85dB @ 1kHz
Input Impedance: Mic in: 1.8K Ohms, typical
Adjustable Gain: +39dB

Inst Input:

Frequency Response: 22Hz to 20kHz (+/-0.2dB)
Dynamic Range: 90dB, A-weighted
Signal-to-Noise Ratio: -90dB, A-weighted
THD+N: <0.0061% (-86dB)
Crosstalk: -75dB @ 1kHz
Input Impedance: Inst in: 500K Ohms, typical;
Total Gain Range: +38dB

Line Inputs (Unbalanced):

Frequency Response: 22Hz to 20kHz (+/-0.2dB)
Dynamic Range: 90dB, A-weighted
Signal-to-Noise Ratio: -90dB, A-weighted
THD+N: <0.003% (-86dB)
Crosstalk: -90dB @ 1kHz
Input Impedance: 10K Ohms, typical

Line Outputs 1/2 (Stereo, Unbalanced):

Frequency Response: 22Hz to 20kHz (+/-0.2dB)
Dynamic Range: 100dB, A-weighted
Signal-to-Noise Ratio: -100dB, A-weighted
THD+N: <0.003% (-86 dB)
Crosstalk: -90dB @ 1kHz
Nominal Output Level: Unbalanced: +2dBV, typical;

Headphone Outputs: (at Maximum Volume; Into 100 Ohm load):

Frequency Response: 22Hz to 20kHz (+/-0.2dB)
Power into Ohms: 20 mW into 100 Ohms
THD+N: <0.06% (-66dB)
Signal-to-Noise Ratio: -100dB, A-weighted
Max Output Level into 100 Ohms: +2.0dBV, typical
Load Impedance: 32 to 600 Ohms

Services

If your Live Console needs servicing, please follow these instructions.

Check our online Help Center at <http://support.iconproaudio.com>, for information, knowledge, and downloads such as:

1. FAQ
2. Downloads
3. Product Registration
2. Video Tutorials

Very often you will find solutions on these pages. If you don't find a solution, create a support ticket at our online Help Center at the link below, and our technical support team will assist you as soon as we can.

Navigate to <http://support.iconproaudio.com> and then sign in to submit a ticket. Once you have submitted an inquiry ticket, our support team will assist you to resolve the problem with your ICON Pro Audio device as soon as possible.

To send defective products for service:

1. Ensure the problem is not related to operation error or external system devices.
2. Keep this owner's manual. We don't need it to repair the unit.
3. Pack the unit in its original packaging including end card and box. This is very important. If you have lost the packaging, please make sure you have packed the unit properly. ICON is not responsible for any damage that occurs due to non-factory packing.
4. Ship to the ICON tech support center or the local return authorization. See our service centers and distributor service points at the link below:

If you are located in US

Send the product to:

North America

Mixware, LLC – U.S. Distributor

3086 W. POST RD.

LAS VEGAS NV 89118

Tel.: (818) 578 4030

Contact: www.mixware.net/help

If you are located in Europe

Send the product to:

Sound Service GmbH

European Headquarter

Moriz-Seeler-Straße3 D-12489 Berlin

Telephone: +49 (0)30 707 130-0

Fax: +49 (0)30 707 130-189

E-Mail: info@sound-service.eu

If you are located in Hong Kong

Send the product to:

ASIA OFFICE:

Unit F, 15/F., Fu Cheung Centre,

No. 5-7 Wong Chuk Yueng

Street, Fotan,

Sha Tin, N.T., Hong Kong.

Tel: (852) 2398 2286

Fax: (852) 2789 3947

Email: info.asia@icon-global.com

5. For additional update information please visit our website at:
www.iconproaudio.com



<p>天猫官方旗舰店</p>  <p>天猫店艾肯旗舰店</p>	<p>抖音号</p>  <p>抖音iCON艾肯</p>	<p>哔哩哔哩</p>  <p>B站iCONProAudio</p>	<p>微信公众号</p>  <p>微信号iCON-PRO</p>	<p>官方售后QQ</p>  <p>4006311312.114.qq.com</p>
--	--	---	---	--

中国地区用户

<p>Twitter</p>  <p>www.twitter.com/iconproaudio</p>	<p>Instagram</p>  <p>www.instagram.com/iconproaudio</p>	<p>Facebook</p>  <p>www.facebook.com/iconproaudio</p>	<p>Youtube</p>  <p>www.youtube.com/iconproaudio</p>
--	--	---	--

<p>Website</p>  <p>www.iconproaudio.com</p>	<p>Support</p>  <p>support.iconproaudio.com</p>	<p>Dashboard</p>  <p>iconproaudio.com/dashboard/</p>
---	---	---

www.iconproaudio.com