

TABLE OF CONTENTS

1. Before You Begin	3
What Is Included	.3
Unpacking Instructions	.3
Claims	
Text Conventions	
Symbols	
Disclaimer	
Safety Notes	
2. Introduction	5
Product Overview	.5
Product Dimensions	.6
3. Setup	7
AC Power	.7
About Dry Ice and CO ₂	.7
Dry Ice Warnings	.7
4. Operation	8
Basic Instructions	.8
Operation	
Safety Shutoff Feature	
5. Technical Information	8
Maintenance	.8
Contact Procedure	.9
CHAUVET® Contact Information	.9
Returning Products to CHAUVET®	.9
6. Technical Specifications1	0

1. BEFORE YOU BEGIN

- Nimbus™ What Is
- Power Cord Included

- Warranty Card
- Quick Reference Guide

Unpacking Carefully unpack the product immediately and check the container to make sure all the parts are in the package and are in good condition. Instructions

Claims If the box or the contents (the product and included accessories) appear damaged from shipping, or show signs of mishandling, notify the carrier immediately, not CHAUVET®. Failure to report damage to the carrier immediately may invalidate your claim. In addition, keep the box and contents for inspection.

> For other issues, such as missing components or parts, damage not related to shipping, or concealed damage, file a claim with CHAUVET® within 7 days of delivery.

Text	Convention	Meaning
Conventions	1 to 512	A range of values
	50/60	A set of values of which only one can be chosen
Symbols	Symbol	Meaning
eyniseis –	\triangle	Critical installation, configuration, or operation information. Not following these instructions may make the product not work, cause damage to the product, or cause harm to the operator.
	Í	Important installation or configuration information. Failure to comply with this information may keep the product from working correctly.
		Useful information.

Disclaimer The information and specifications contained in this document are subject to change without notice. CHAUVET® assumes no responsibility or liability for any errors or omissions that may appear in this manual. CHAUVET® reserves the right to update the existing document or to create a new document to correct any errors or omissions.

You can download the latest version of this document from www.chauvetlighting.com. © Copyright 2014 CHAUVET®. All rights reserved.


Electronically published by CHAUVET® in the United States of America.

Author	Date	Editor	Updated
M. Trouard	07/03/14	D. Couppe	07/07/14


Safety Notes	Please read the following Safety Notes carefully before working with the product. The notes include important safety information about installation, usage, and maintenance.
Â	 Always connect the product to a grounded circuit to avoid the risk of electrocution. Always disconnect the product from the power source before cleaning. Make sure the power cord is not crimped or damaged. Never disconnect the product from power cord by pulling or tugging on the cord. Make sure there are no flammable materials close to the product when operating. Do not touch the product's housing when operating because it may be very hot. Do not mount the product on a flammable surface (linoleum, carpet, wood, paper, carton, plastic, etc.). The product's nozzle is very hot during operation and it remains hot for a long time after operation has stopped. The CO₂ exits the nozzle at a very high temperature. Keep a minimum distance of 6.5 ft (2 m) from the nozzle to the nearest object. Do not use the product as a space heater. Do not swallow dry ice. It may lead to severe internal injuries. Before breaking the dry ice, cover it with a piece of cloth or place the block in a cloth bag. Eye protection must be worn. Do not use in a confined space. Make sure the room is well ventilated before beginning usage. Dry ice should never be stored in a sealed container. It can lead to a pressure build-up and a risk of an explosion.
(j)	 For safety reasons, we do not recommend mounting the product in any capacity. Operate the product while it is on the ground only. During warm up and operation, water will be scolding hot. Do not place your hand into the water. Do not remove basket when the unit is plugged in or when heaters are hot.
Ĺ	 Always make sure that the voltage of the outlet to which you are connecting the product is within the range stated on the decal or rear panel of the product. The product is for indoor use only! (IP20) To prevent risk of fire or shock, do not expose the product to rain or moisture. Always install the product in a location with adequate ventilation, at least 20 in (50 cm) from adjacent surfaces. Be sure that no ventilation slots on the product's housing are blocked. Never connect the product from the power cord or any moving part. The maximum ambient temperature (Ta) is 104 °F (40 °C). Do not operate the product at higher temperatures. In the event of a serious operating problem, stop using the product immediately. Never try to repair the product. Repairs carried out by unskilled people can lead to damage or malfunction. Please contact the nearest authorized technical assistance center. Do not continue to use the machine once visibility is reduced to 20" (50 cm) or below. The area in front of the product may become wet during operation. Make sure not to use near smooth floors as they may become slippery.
	 Water temperature should be about 175 °F (79 °C) for optimal operation. Keep this User Manual for future consultation. If you sell the product to another user, be sure that they also receive this document.

2. INTRODUCTION

Product Overview



Product Dimensions



3. Setup

AC Power The Nimbus[™] has a fixed voltage power supply and can work with an input voltage of either 120 VAC, 60 Hz or 230 VAC, 50 Hz, depending on the specific model.

> To determine the product's power requirements (circuit breaker, power outlet, and wiring), use the current value listed on the label affixed to the product's back panel, or refer to the product's specifications chart. The listed current rating indicates the product's average current draw under normal conditions.



Always connect the product to a protected circuit (circuit breaker or fuse). Make sure the product has an appropriate electrical ground to avoid the risk of electrocution or fire.



Never connect the product to a rheostat (variable resistor) or dimmer circuit, even if the rheostat or dimmer channel serves only as a 0 to 100% switch.

About Dry Ice Dry ice is a solid form of carbon dioxide. The term "dry ice" is used because of its ability to sublimate — the process of transforming from a solid directly to a gas without any and CO₂ liquid formation. Dry ice reaches a temperature of -189.5 °F (-87.5 °C).

When immersed in hot or boiling water, dry ice sublimates and agitates the water. The releases cold CO₂ gas causes the water vapor to form water droplets in the air. This expansion of gas and moisture pushes its way out of the machine. Because the CO₂ is cold and heavy, the moisture sinks to the floor. The droplets in the air create the fog effect.

Dry Ice Warnings

DO NOT cover or plug the output nozzle during operation. Compressing the dry ice will cause a chemical reaction that may lead to an explosion.

Do not handle dry ice with bare hands. Thick gloves must be worn.

Do not swallow dry ice. It will lead to severe internal injuries.



- Before breaking the dry ice, cover it with a piece of cloth or place the block in a cloth bag. Eye protection must be worn.
- Do not use in a confined space. Make sure the room is well ventilated before beginning usage.
- Dry ice should never be stored in a sealed container that can lead to a pressure build-up and a risk of an explosion.

4. OPERATION

Basic · Instructions

The top plate has two LED indicators - one red and one green. The red LED indicates that the heater is on, and the green LED indicates when the water is at its optimal operating temperature. The heater will not turn on unless there is enough water

- As the dry ice sublimates, the green LED indicator will turn off indicating that the water temperature has dropped below its optimal operating temperature. This is normal and the Nimbus[™] will continue to operate until all the dry ice has been used.
- During operation, the top plate becomes very hot. DO NOT TOUCH!
- There is an optional power input next to the main power input to increase the rate in which the water is heated. Use the included power cable and connect this secondary input to a separate circuit to heat the water in half the time. Do not plug both power cords into the same circuit as the breaker will trip.
- The dry ice must be stored inside the internal basket for optimal performance. Do not remove this basket as serious bodily injury may occur.

Operation 1. Place the machine on a level surface. Plug the power cord into the wall.

- 2. Raise the basket to its highest level with the operation lever.
- Open the lid and fill with water until the red light comes on. The container can hold up 3. to 4.5 gallons (17 liters).
- 4. Using protective gear, load the basket with up to 10 lb of dry ice. The dry ice should be loaded at the last possible moment.
- 5. Close and latch the lid.
- 6. Grab the operating lever and slowly lower the handle to the middle notch for low output or all the way down for high output.
- 7. When output slows or stops, raise and refill the basket.



Due to water evaporation, you may need to refill the Nimbus™ with water to trigger the red LED indicator. Once the red light comes on, repeat steps 4 through 7.

Feature

Safety Shutoff The Nimbus™ is fitted with a safety shutoff feature, which prevents the unit's heaters from turning on when the water level is too low. If this safety shutoff feature has been engaged, simply add more water to continue using the Nimbus™.

5. TECHNICAL INFORMATION

Maintenance The Nimbus requires minimal upkeep in order to maintain optimum performance. However, some steps are needed in order to clean and maintain the product for maximum usage. The recommended procedure is as follows:

- 1. After use, wait for the machine and any remaining water inside to fully cool down.
- Dump all cooled water from the internal tank from the product. You may risk bodily 2. harm and damage to transport items if the water is still hot.

Contact Procedure	 In the U.S., In the UK or 		® Europe Ltd.	
CHAUVET® Contact Information	CHAUVET®		CHAUVET® General Info Address:	•
	Technical Suppo	ort	Technical Su	Ipport
	Voice: Fax: Email:	(954) 577-4455 (Press 4) (954) 756-8015 <u>tech@chauvetlighting.com</u>	Email:	uktech@chauvetlighting.com
	World Wide Web World Wide Web			Web
		www.chauvetlighting.com		www.chauvetlighting.co.uk



If you live outside the U.S., United Kingdom, or Ireland, contact your distributor of record and follow their instructions on how to return CHAUVET® products to them. Visit our website for contact details.

Products to CHAUVET®

Returning Call the corresponding CHAUVET® Tech Support office and request a Return Merchandise Authorization (RMA) number before shipping the product. Be prepared to provide the model number, serial number, and a brief description of the cause for the return.

> You must send the merchandise prepaid, in its original box, and with its original packing and accessories. CHAUVET® will not issue call tags.

> Clearly label the package with the RMA number. CHAUVET® will refuse any product returned without an RMA number.



Write the RMA number on a properly affixed label. DO NOT write the RMA number directly on the box.

Before sending the product, clearly write the following information on a piece of paper and place it inside the box:

- Your name
- Your address
- Your phone number
- RMA number
- A brief description of the problem

Be sure to pack the product properly. Any shipping damage resulting from inadequate packaging will be your responsibility. FedEx packing or double-boxing are recommended.



CHAUVET® reserves the right to use its own discretion to repair or replace returned product(s).

imensions and	Length	Width	Height	Weight
Weight	20 in (513 mm)	18 in (465 mm)	19 in (470 mm)	Empty: 28.6 lb (13 kg Full: 75 lb (34 kg)
	Note: Dimensions in inches r	Note: Dimensions in inches rounded to the nearest decimal digit.		
Power	Power Supply Type	R	ange	Voltage Selection
	Model specific	120 V, 60 Hz	or 230 V, 50 Hz	Voltage specific
	Parameter	Parameter 120 V,		230 V, 50 Hz
	Consumption (Single Elemer	nt) 15	00 W	1400 W
	Consumption(Dual Element	t) 30	00 W	3000 W
	Operating (Single Element) 1:	2.6 A	6.2 A
	Operating (Dual Element)	25	5.2 A	12.3 A
	Power I/O	US/W	orldwide	UK/Europe
	Power input connector	Neutrik® p	owerCON® A	Neutrik® powerCON® A
Heat	Parameter	Heat	Up Time	Reheat Time
	Single Element	50) min	30 min
	Dual Element	30) min	15 min
	Average Runtime	Tank	Capacity	Dry Ice Capacity
	6 min	4.5 g	jal (17 l)	10 lb (4.5 kg)
Thermal	Maximum External Temp	. Max Water	Temperature	
	104 °F (40 °C)	175 º	F (79 °C)	
Ordering	Product Name	Iten	n Code	Item Number
	Nimbus™ (120 V)	090	50429	NIMBUS
	Nimbus™ (220 V)	090	50451	220VNIMBUS
	$\boldsymbol{\ell}$	UL 15	73	RoHS
	(ME	ET 🖲 CSA C	22.2 No. 166	
	c	US E113	093	
				IXI
				XX

6. TECHNICAL SPECIFICATIONS